



Recessed View

**Material:** 304 SST  
**Work Load:** 1000 lbs  
**Configurations:** With or without cover  
**Manufactured:** Minnesota, USA

**Notes:**

1. To properly install anchors either an engineer or architect should be consulted to determine the proper depth of concrete per soil condition.
2. Anchor pullout strength may vary depending on concrete condition.
3. All dimensions are in inches.

<b>ANCHOR MFG</b> Eagan, Minnesota		
<b>PL0010 Assembly</b>		
SIZE <b>B</b>	<b>PL0010</b>	REV <b>A</b>