



**Material:** 304 SST  
**Work Load:** 5000 lbs  
**Configurations:** With or without cover  
**Manufactured:** Minnesota, USA

Note: 1. To properly install anchors either a engineer or architect should be consulted to determine the proper depth of concete per soil condition.  
 2. Work load may very depending on soil condition.  
 3. All Dimensions are in Inches.

<b>ANCHOR MFG</b> Eagan, Minnesota		
<b>BLC5000 Assembly</b>		
SIZE <b>B</b>	<b>BLC5000</b>	REV <b>A</b>

Optional Cover