



Material: 304 SST
Work Load: 3500 lbs
Configurations: With or without cover
Manufactured: Minnesota, USA

Note: 1. To properly install anchors either an engineer or architect should be consulted to determine the proper depth of concrete per soil condition.
 2. Work load may vary depending on soil condition.
 3. All Dimensions are in Inches.

ANCHOR MFG Eagan, Minnesota		
AN3500 Assembly		
SIZE B	AN3500	REV B