

Material: 304 SST Work Load: 2000 lbs Configurations: With or without cover Manufactured: Minnesota, USA

## Notes:

- To properly install anchors either an engineer or architect should be consulted to determine the proper depth of concete per soil condition.
  Work load may very depending on soil condition.
  All dimensions are in inches.

