



**Material:** 304 SST  
**Work Load:** 3500 lbs  
**Configurations:** With or without cover  
**Manufactured:** Minnesota, USA

Note: 1. To properly install anchors either a engineer or architect should be consulted to determine the proper depth of concrete per soil condition.  
 2. Work load may vary depending on soil condition.  
 3. All Dimensions are in Inches.

<b>ANCHOR MFG</b>		
Eagan, Minnesota		
BL3500 Assembly		
SIZE <b>B</b>	BL3500	REV <b>A</b>