



Optional Cover

**Material:** 304 SST  
**Work Load:** 10000 lbs  
**Configurations:** With or without cover  
**Manufactured:** Minnesota, USA

**Notes:**

1. To properly install anchors either an engineer or architect should be consulted to determine the proper depth of concete per soil condition.
2. Anchor pullout strength may vary depending on soil condition.
3. All dimensions are in inches.

**ANCHOR MFG**  
 Eagan, Minnesota

**AN10000 Assembly**

SIZE		REV
<b>B</b>	<b>AN10000</b>	<b>A</b>