

To properly install anchors either an engineer or architect should be consulted to determine the proper depth of concete per soil condition.
 Work load may very depending on soil condition.
 All dimensions are in inches.

ANCHOR MFG Eagan, Minnesota		
SL5000 Assembly		
SIZE <b>B</b>	SL5000	REV <b>A</b>